




## BAG BUNKER™ ASSEMBLY & SET-UP GUIDE



Contents: 6 - Bag Bunkers™  
12 - Support Pads (2 each)  
24 - Support Rods (4 each)  
24 - Adhesive Strips (4 each)



Unfold and lay out Support Pad on a flat surface with the two side grooves face up.



Place 1 Support Rods into each side groove (2) in the Support Pad, and press in place.



Remove the white backing of the two Adhesive Strips and place one over each of the Rods in the grooves and press firmly.



Once Adhesive Strips are secure, remove the Bag Bunker™ from the plastic.



Unfold and lay out Bag Bunker™ on a flat surface.



Unzip the tops of both sides of the Bag Bunker™.



Open Bag Bunker™ red side up. Unclip both straps.




Slide an assembled Support Pad into the open bottom of one side of Bag Bunker™. Easier with two people.



Zip the top of that side of the Bag Bunker™ closed.



Repeat steps 9 & 10 on 2nd side of Bag Bunker™.



Next attach triangle top by lining up the velcro and securing it.



Repeat by attaching the triangle bottom using the velcro.



Now attached straps by criss crossing them for more support.



After attaching the second strap it should create an "X." Be sure straps are tight to give the most support.



Now stand Bag Bunker™ up and adjust straps if necessary. If straps do not make an "X" Bunkers will not stand properly. Repeat steps 2-15 for the remaining Bunkers.




When finished playing and ready to store Bag Bunkers™, simply unstrap, and re-strap to the original clips and tighten straps



Fold triangle top and bottom inside, then fold Bag Bunker™ in half and zip closed. **Support Pads should remain inside Bunker.**




There are many storage uses for the Bag Bunkers™. One Bunker will hold up to 10 assembled bows.



One Bunker will hold up to 24 arrows.



If using outdoors, anchor Bag Bunkers™ by staking to the ground using the three "D" Rings.



This is the proper way to set up your Bag Bunkers™ on an Extreme Archery field.

v. 2.0

**ARCHERYTAG.COM**

101 Archery Way, Ashley, IN 46705  
260.587.4500  
info@globalarchery.com



Archery Tag® is a registered trademark of Global Archery Products, Inc. Registered in the U.S. and other countries.  
© 2023 Global Archery Products, Inc., All Rights Reserved.

