



## BAG BUNKER™ 4.0 SET-UP GUIDE



Start by unzipping Bag Bunker™ all the way (3 sides).



Open the Bag Bunker™ and lay out (red side up).




Fold out top and bottom triangle panels.




Lift one half of the Bunker so you can attached the top triangle to the side.



Line up the snaps and press firmly until they click. Press along the velcro for extra security.



Now line up snaps on the bottom triangle with the side.



Again, press firmly on snaps and velcro.



Tighten inside straps if needed.



Stand Bag Bunker™ up.



Now you are ready to set up your Extreme Archery field.



When finished playing and ready to store Bag Bunkers™, simply unsnap triangles and fold them inside..



Fold Bag Bunker™ in half and zip closed.



13 To store bows or arrows inside the Bag Bunker™. First unzip Bunker and release strap clips.




14 Lay unstrung assembled bows inside the Bunker.



15 Reattach strap clips. Pull on strap end to tighten. One Bunker will hold up to 10 assembled bows.




16 One Bunker will hold up to 24 arrows.



17 If using outdoors, in windy conditions you may wish to anchor Bag Bunkers™ by staking to the ground using the three "D" Rings.



18 Now let's have some fun!



This is the proper way to set up your Bag Bunkers™ on an Extreme Archery field.

v. 4.0

**ARCHERYTAG.COM**

101 Archery Way, Ashley, IN 46705  
260.587.4500  
[info@globalarchery.com](mailto:info@globalarchery.com)



Archery Tag® is a registered trademark of Global Archery Products, Inc. Registered in the U.S. and other countries.  
© 2025 Global Archery Products, Inc., All Rights Reserved.

